

FreeIPMI Frequently Asked Questions

Free Intelligent Platform Management System
Version 1.1.5 updated on 18 May 2012

by Albert Chu chu11@l1nl.gov

Copyright © 2003-2012 FreeIPMI Core Team

This manual is for FreeIPMI (version 1.1.5, 17 May 2012). Copyright © 2006-2012 FreeIPMI Core Team

Permission is granted to copy, distribute and/or modify this document under the terms of the GNU Free Documentation License, Version 1.2 or any later version published by the Free Software Foundation; with no Invariant Sections, no Front-Cover Texts, and no Back-Cover Texts.

Table of Contents

0.1	IPMI - Platform Management Standard	1
0.2	What is FreeIPMI?	1
0.3	How did FreeIPMI start?	1
0.4	What operating systems does FreeIPMI run on?	1
0.5	FreeIPMI vs OpenIPMI vs Ipmitool vs Ipmitool	2
0.6	What is special about FreeIPMI?	2
0.7	Does my system support IPMI?	4
0.8	How do I compile FreeIPMI?	5
0.9	libgcrypt requirement	5
0.10	x86-64 Compilation	5
0.11	Installing FreeIPMI on FreeBSD	5
0.12	What are some IPMI terminology or acronyms I should be aware of?	5
0.13	What setup is needed for FreeIPMI to communicate over LAN?	6
0.14	What setup is needed for Serial over LAN (SOL) or Ipmiconsole?	6
0.15	Do I need to install or configure a driver to perform IPMI inband?	7
0.16	SSIF Driver Configuration	7
0.17	How do you setup Powerman with ipmipower?	8
0.18	How do you setup Conman with ipmiconsole or libipmiconsole?	9
0.19	How do you setup Ganglia or Nagios to monitor IPMI sensors via FreeIPMI?	9
0.20	Why is the IPMI kernel driver faster than the KCS driver?	9
0.21	Why are there so many IPMI compliance bugs?	9
0.22	How do I get around an IPMI compliance bug on my motherboard?	10
0.23	How do I program with the FreeIPMI libraries?	10
0.24	Where can I get additional help or support?	10

0.1 IPMI - Platform Management Standard

The IPMI specifications define standardized, abstracted interfaces to the platform management subsystem. IPMI includes the definition of interfaces for extending platform management between the board within the main chassis and between multiple chassis.

The term platform management is used to refer to the monitoring and control functions that are built in to the platform hardware and primarily used for the purpose of monitoring the health of the system hardware. This typically includes monitoring elements such as system temperatures, voltages, fans, power supplies, bus errors, system physical security, etc. It includes automatic and manually driven recovery capabilities such as local or remote system resets and power on/off operations. It includes the logging of abnormal or out-of-range conditions for later examination and alerting where the platform issues the alert without aid of run-time software. Lastly it includes inventory information that can help identify a failed hardware unit.

0.2 What is FreeIPMI?

FreeIPMI is a collection of Intelligent Platform Management IPMI system software. It provides in-band and out-of-band software and a development library conforming to the Intelligent Platform Management Interface (IPMI v1.5 and v2.0) standards. FreeIPMI also supports IPMI-related specifications such as the Data Center Management Interface (DCMI) and Intel Node Manager.

0.3 How did FreeIPMI start?

In October 2003, California Digital Corp. (CDC) was contracted by Lawrence Livermore National Laboratory (LLNL) for the assembly of Thunder, a 1024 node Itanium2 cluster. This led to software developers from CDC and LLNL merging the IPMI software developed by both organizations into FreeIPMI.

Anand Babu, Balamurugan and Ian Zimmerman at CDC contributed the in-band KCS driver, ipmi-sensors, bmc-config, ipmi-sel, bmc-info, and portions of libfreeipmi. Albert Chu and Jim Garlick at LLNL contributed ipmipower, bmc-watchdog, ipmiping, rmcpping, portions of libfreeipmi, and ipmi support in Powerman. In October 2004, FreeIPMI 0.1.0 was officially released.

Since the 0.1.0 release, Z Research developers have contributed ipmi-chassis, ipmi-raw, ipmi-locate, and portions of ipmi-pef-config. LLNL has contributed IPMI 2.0 support, hostrange support, ipmiconsole, libipmiconsole, ipmidetect, ipmi-sensors-config, ipmi-chassis-config, bmc-device, ipmi-oem, ipmi-dcml, libipmimonitoring, and portions of ipmi-pef-config.

(Note: The original FreeIPMI developers from California Digital Corp. are now at Zresearch Inc.)

0.4 What operating systems does FreeIPMI run on?

FreeIPMI was originally developed on GNU/Linux. It has been confirmed to be built on most major GNU/Linux distributions such as Redhat, Fedora, Suse, and Debian. FreeIPMI has been ported and confirmed to work on at least FreeBSD, OpenBSD, Solaris, OpenSolaris, and Windows via Cygwin. We imagine it would build cleanly on other operating systems.

If it doesn't, it should be easily portable to them. Please contact the maintainers on the freeipmi-devel@gnu.org mailing lists.

0.5 FreeIPMI vs OpenIPMI vs Ipmitool vs Ipmiutil

There are multiple implementations, APIs, interfaces, end user requirements, etc. that one can choose when developing IPMI drivers, libraries, and tools. FreeIPMI has taken some different approaches than other open-source projects.

The section below points out a number of the reasons why we feel FreeIPMI is particularly special compared to the other projects.

The Ipmiutil project has a good chart describing many of the differences between the projects: <http://ipmiutil.sourceforge.net/docs/ipmisw-compare.htm>.

0.6 What is special about FreeIPMI?

In our eyes, there are several reasons why FreeIPMI is particularly special.

- 1) Support for HPC and large data centers

A number of features have been added into the tools to support HPC and/or large data centers. Much of this original support was added to support the large cluster environments at Lawrence Livermore National Laboratory (LLNL).

Scalable parallel execution of many FreeIPMI tools (ipmi-sensors, ipmi-sel, bmc-info, etc.) across a cluster is supported through hostranged input and output. For example:

```
# > bmc-info -h "pwopr[0-5]" -u XXX -p XXX --get-device-id -C
```

```
-----
pwopr[0-1,5]
```

```
-----
Device ID           : 34
Device Revision     : 1
Device SDRs         : unsupported
Firmware Revision   : 1.0c
Device Available    : yes (normal operation)
IPMI Version        : 2.0
Sensor Device       : supported
SDR Repository Device : supported
SEL Device          : supported
FRU Inventory Device : supported
IPMB Event Receiver  : unsupported
IPMB Event Generator : unsupported
Bridge              : unsupported
Chassis Device       : supported
Manufacturer ID      : Peppercon AG (10437)
Product ID          : 4
Auxiliary Firmware Revision Information : 38420000h
```

```
-----
pwopr[2-4]
```

```

Device ID           : 34
Device Revision     : 1
Device SDRs         : unsupported
Firmware Revision   : 1.17
Device Available    : yes (normal operation)
IPMI Version        : 2.0
Sensor Device       : supported
SDR Repository Device : supported
SEL Device          : supported
FRU Inventory Device : supported
IPMB Event Receiver  : unsupported
IPMB Event Generator : unsupported
Bridge              : unsupported
Chassis Device       : supported
Manufacturer ID     : Peppercon AG (10437)
Product ID          : 4
Auxiliary Firmware Revision Information : 38420000h

```

In the above example, its clear to see that pwopr[2-4] have different firmware than pwopr[0-1,5]. More information about hostrange support can be found in the document freeipmi-hostrange.txt (<http://www.gnu.org/software/freeipmi/freeipmi-hostrange.txt>).

Ipmipower is capable of scaling to large nodes for cluster support and is supported by Powerman (<http://code.google.com/p/powerman/>) for scalable power management. At LLNL, in conjunction with Powerman, ipmipower is used for power control on clusters ranging from sizes of 4 to 2000. It has been used to determine power status or power control LLNL's largest clusters in under a second.

Ipmiconsole is currently supported by Conman (<http://conman.googlecode.com/>) for scalable console management.

Ipmi-sensors and libipmimonitoring are capable of interpreting sensor readings as well as just reporting them. It can be used for host monitoring IPMI sensor severity on a cluster. By mapping sensor readings into NOMINAL, WARNING, or CRITICAL states, it makes monitoring sensors easier across large numbers of nodes. Skummee (<http://sourceforge.net/projects/skummee>) currently uses libipmimonitoring to monitoring sensors on LLNL clusters of up to 2000 nodes in size. FreeIPMI sensor monitoring plugins for Ganglia (<http://ganglia.info/>) and Nagios (<http://www.nagios.org/>) have also been developed and made available for download (<http://www.gnu.org/software/freeipmi/download.html>).

Ipmi-sel and libipmimonitoring are capable of interpreting system event log (SEL) entries as well as just reporting them. It can be used for host monitoring IPMI event severity on a cluster. By mapping events into NOMINAL, WARNING, or CRITICAL states, it makes monitoring system events easier across large numbers of nodes. Skummee (<http://sourceforge.net/projects/skummee>) currently uses libipmimonitoring to monitoring the SEL on LLNL clusters of up to 2000 nodes in size.

The bmc-config, ipmi-chassis-config, ipmi-pef-config, ipmi-sensors-config, and configuration file and command-line interface are used to easily copy the BMC configuration from one node to every other node in a cluster quickly. It has been used to modify the BMC

configuration across large LLNL clusters in a few minutes. They also have the capability to verify (via the diff option) that the desired configuration has been properly stored to firmware.

Ipmidetector can be used to enhance the efficiency of the hostranged input by eliminating those nodes in the cluster that have been temporarily removed for servicing.

2) Additional OEM support

FreeIPMI contains support for a number of OEM extensions and OEM sensors and/or events. Ipmi-oem currently supports OEM command extensions for motherboards made by Dell, Fujitsu, IBM, Intel, Inventec, Quanta, Sun Microsystems, and Supermicro. Ipmi-sensors and Ipmi-sel support OEM sensors and/or events for motherboards made from Dell, Fujitsu, Intel, Inventec, Quanta, Sun Microsystems, and Supermicro. (Some of the motherboards may have been rebranded by vendors, see manpages for official list of confirmed supported motherboards.)

3) Additional flexibility and features

By implementing various IPMI sub-sections into multiple tools, each tool is capable of providing the user with more flexibility and ultimately more features in addition to those listed above. It may not be as easy (or architecturally possible) to do in an all-in-one tool.

4) Extra IPMI support

In addition to the features listed above, FreeIPMI also supports specifications related to IPMI. The Data Center Management Interface, or DCMI, is supported via the FreeIPMI tool ipmi-dcmi. Some aspects of the Intel Power Node Manager are supported in ipmi-oem.

5) Easy setup

By implementing drivers in userspace libraries, there is no need to build/setup/manage any kernel modules/drivers.

6) Portability

Likewise, by implementing everything in userspace libraries and tools, portability to multiple operating systems and architectures should be easier.

0.7 Does my system support IPMI?

Unfortunately, there are no universally defined mechanisms for determining if a system supports IPMI. The following may provide hints.

1) FreeIPMI's ipmi-locate can be used to determine if IPMI can be found on your system. Users are cautioned though, the failure to discover IPMI via ipmi-locate is not sufficient to disprove that IPMI exists on your system. Your system may not publish such information or may expect clients to communicate at default locations.

2) dmidecode may be similarly used to probe for devices that support IPMI on your system. You may grep for IPMI or specifying the IPMI DMI type on the command line.

```
# > dmidecode --type 38
# dmidecode 2.10
SMBIOS 2.5 present.
```

```
Handle 0x0049, DMI type 38, 18 bytes
IPMI Device Information
```

```

Interface Type: KCS (Keyboard Control Style)
Specification Version: 2.0
I2C Slave Address: 0x10
NV Storage Device: Not Present
Base Address: 0x00000000000000CA2 (I/O)
Register Spacing: Successive Byte Boundaries

```

Again, the failure to find an IPMI supported device is not sufficient to show lack of IPMI support.

Ultimately, some amount of information from product documents or trial and error may be necessary to determine if IPMI is supported on your system.

0.8 How do I compile FreeIPMI?

Please see the README.build instructions provided with FreeIPMI or on the FreeIPMI website's documentation (<http://www.gnu.org/software/freeipmi/README.build>).

0.9 libgcrypt requirement

FreeIPMI requires the libgcrypt library to be installed for a variety of encryption requirements in IPMI 2.0. If you are building FreeIPMI and receive a 'libgcrypt required to build libfreeipmi' error, please install libgcrypt. For Linux users, this may require the install of the libgcrypt-devel package as well. For those who do not need IPMI 2.0 encryption, FreeIPMI may be built without it by specifying `--without-encryption` when executing configure.

0.10 x86-64 Compilation

By default, FreeIPMI's build autotools (e.g. configure) should detect if you are on a 64 bit system and should build against 64 bit libraries. However, some multi-architecture installs (e.g. you have 32 bit and 64 bit libraries installed) may lead to builds and installs of 32 bit instead of 64 bit. For those noticing this, pass `libdir` appropriately to the configure script to workaround this problem. (e.g. `--libdir=/usr/lib64`)

Example:

```
# ./configure --prefix=/usr --libdir=/usr/lib64
```

0.11 Installing FreeIPMI on FreeBSD

You can install a binary package of `freeipmi` or use the port, located in `ports/sysutils/freeipmi`, to build it from the source. See `ports(7)` and 'Packages and Ports' section (http://www.freebsd.org/doc/en_US.ISO8859-1/books/handbook/ports.html) in The FreeBSD Handbook.

Please contact port maintainer (MAINTAINER line in the port's Makefile), if you have problems building from the port.

0.12 What are some IPMI terminology or acronyms I should be aware of?

Good question, here are some terms and acronyms with general definition you might want to know.

BMC stands for **Baseboard Management Controller**. The BMC is the management chip on the system that is responsible for IPMI. It is common to refer to configuring the “BMC” as synonymous for configuring IPMI.

inband IPMI communication refers to communication on a system locally (i.e. not over a network).

outofband and **IPMI over LAN** refer to IPMI communication over a network, typically ethernet.

SDR stands for **Sensor Data Repository**. The SDR is a database of system information that is needed by many other IPMI functions. It is commonly read before some IPMI action can be taken. For example, it contains a list of all sensors on a system, so it must be downloaded before sensors on a system can be read. In FreeIPMI, the SDR is cached in a common location and can be used by a number of tools, such as `ipmi-sensors`, `ipmi-sel`, and `ipmi-fru`.

SEL stands for **System Event Log**. The SEL is a log of events stored on the system for later diagnostics. In FreeIPMI, `ipmi-sel` can be used to read the SEL.

FRU stands for **Field Replaceable Unit**. While FRU is a general computing term referring to a replaceable unit of electronics, in IPMI it is common to refer to the “FRU” as the database of all FRU components on a system. In FreeIPMI, `ipmi-fru` can be used to read the FRU components on a system.

PEF stands for **Platform Event Filtering**. PEF refers to the rules that determine when PETs are generated and where they are sent. In FreeIPMI, PEF can be configured via `ipmi-pef-config`.

PET stands for **Platform Event Trap**. PET refers to a trap that can be sent by a system to an SNMP agent to indicate an event has occurred on the system. In FreeIPMI, a PET trap can be interpreted via `ipmi-pet`.

DCMI stands for **Data Center Management Interface**. DCMI is a management interface defined by a group of vendors that use IPMI as the backend for their system management definition. In FreeIPMI, `ipmi-dcml` can be used to read/configuring DCMI.

SOL stands for **Serial over LAN**. SOL refers to the forwarding of serial system traffic over a network, typically an ethernet network. It is typically used to access a remote system console. In FreeIPMI, `ipmiconsole` is used to access a remote console via SOL.

RMCP stands for **Remote Management Control Protocol**. The RMCP protocol is another remote management protocol which IPMI is defined within for outofband communication. For most IPMI users, you will never need to know about RMCP.

0.13 What setup is needed for FreeIPMI to communicate over LAN?

Please see the `bmc-config.conf(5)` manpage provided with FreeIPMI for details, or you can read it on the FreeIPMI website’s documentation (<http://www.gnu.org/software/freeipmi/manpages/man5>).

0.14 What setup is needed for Serial over LAN (SOL) or Ipmiconsole?

The setup of Serial-over-LAN (SOL) and/or `Ipmiconsole` is highly dependent on your system. However, most motherboards require the following:

1) Adjust the BIOS COM port for serial redirection over SOL instead of the normal serial port and set the appropriate baud rate. If you do not know which port is the SOL port, you may need to play around and guess. It is likely a non-default setting, since many manufacturers may still assume the default redirection is out of the normal serial port. If you do not have a serial port on your motherboard, this part can probably be skipped.

2) Configure IPMI on the motherboard to use SOL. Many motherboards may have this enabled by default, however you may wish to verify with FreeIPMI's `bmc-config`. More information can be found in the `bmc-config.conf(5)` manpage on the settings. However, the key settings are to enable SOL on the system, enable SOL for individual users, and select the appropriate baud. On many motherboards, the selected baud must match what is configured in the BIOS.

3) Adjust your operating systems serial console settings to use the appropriate COM port. For Linux, the following guide (<http://www.vanemery.com/Linux/Serial/serial-console.html>) provides a pretty good overview of setting of a serial console on Linux. The only difference for setting up a serial console with `Ipmiconsole` or SOL, is the `ttySX` terminal may need to be changed.

0.15 Do I need to install or configure a driver to perform IPMI inband?

For most people the answer is no.

FreeIPMI includes a userspace driver that works on most motherboards without any driver installation, loading, or configuration required. FreeIPMI also includes support of a Linux SSIF driver through the SSIF device (i.e. `/dev/i2c-0`), the OpenIPMI Linux kernel driver (i.e. `/dev/ipmi0`), and the Sun/Solaris BMC driver (i.e. `/dev/bmc`). If you communicate through one of these mechanisms, the appropriate drivers for them should be loaded. Most systems should automatically load the appropriate drivers you need.

Under most scenarios, the FreeIPMI tools should automatically discover which in-band interface to use and the proper settings to use. Some motherboards may require you to determine alternate configurations for addresses, paths, etc. on your own and pass them as command line options to the tools.

Every system is different and your situation may differ. Please see your manufacturer and operating system instructions.

There are some additional Linux OpenIPMI kernel driver notes here: <http://www.gnu.org/software/freeipmi/README.openipmi>.

0.16 SSIF Driver Configuration

FreeIPMI's SSIF driver works on top of kernel's `i2c` device interface.

Under GNU/Linux load these kernel modules: `i2c-dev`, `i2c-i801`, `i2c-core` before using FreeIPMI.

To identify SSIF device address:

Example:

```
$> lspci (in the output look for this entry)
00:1f.3 SMBus: Intel Corp. 6300ESB SMBus Controller (rev 01)
```

```
Subsystem: Intel Corp.: Unknown device 342f
Flags: medium devsel, IRQ 17
I/O ports at 0400 [size=32]
```

```
$> cat /proc/bus/i2c
i2c-0    smbus      SMBus I801 adapter at 0400          Non-I2C SMBus adapter
```

Make sure the "0400" above matches with the "0400" address under proc. Also make sure "i2c-0" is not different. If it appears different then grep for "i2c-0" in this code "ipmitool.c" and change. "i2c-X" is the label assigned to each slave device attached on the i2c bus.

BMC address Locator:

Refer to the SM BIOS IPMI Device Information Record Type 38, record 06h and 08h. Use the value of record 06h as the IPMBAddress and load the SMBus controller driver at the address value read from record 08h.

Usual values for record 06h -> 0x42

Usual values for record 08h -> 0x400

0.17 How do you setup Powerman with ipmipower?

There are additional details in the Powerman (<http://code.google.com/p/powerman/>) documentation, however here are the basics. In the powerman.conf file, you want to include the ipmipower.dev device file, setup an ipmipower device in co-process mode, then configure hosts to use that device.

```
include "/etc/powerman/ipmipower.dev"

device "ipmi0" "ipmipower" "/usr/sbin/ipmipower -h mynodes[0-10] |&"

node "mynodes[0-10]" "ipmi0" "mynodes[0-10]"
```

You may wish to add some additional ipmipower configuration on the device line:

```
device "ipmi0" "ipmipower" "/usr/sbin/ipmipower --wait-until-on --wait-until-off -h my
```

although you will probably want to do some of this configuration (especially the username and password) in freeipmi.conf.

If you use an alternate set of hostnames for IPMI from the primary hostname, that can be configured like this:

```
device "ipmi0" "ipmipower" "/usr/sbin/ipmipower -h altname[0-10] |&"

node "primaryname[0-10]" "ipmi0" "altname[0-10]"
```

0.18 How do you setup Conman with ipmiconsole or libipmiconsole?

There are additional details in the Conman (<http://conman.googlecode.com/>) documentation and manpages, however here are some basics.

To configure Conman to connect via the ipmiconsole tool, Conman comes with an expect script named ipmiconsole.exp, typically installed into /usr/lib/conman/exec/ipmiconsole.exp. Consoles can be setup by adding lines to conman.conf like:

```
CONSOLE name="myserver" dev="/usr/lib/conman/exec/ipmiconsole.exp myserver myusername"
```

One of the useful aspects of using the ipmiconsole.exp script is that the same configuration options you may have already configured into freeipmi.conf, may be loaded automatically when ipmiconsole is executed via this expect script.

However, as can be expected, scalability may be a problem as you must launch a process for every node in your cluster.

Conman is also capable of connecting to servers natively through the libipmiconsole library, so that no additional processes are launched. They can be configured as follows:

```
CONSOLE name="myserver" IPMI_OPTS="U:myusername,P:mypassword" dev="ipmi:myserver"
```

on some older versions of Conman, you would instead use

```
CONSOLE name="myserver" IPMI_OPTS="myusername,mypassword" dev="ipmi:myserver"
```

Please see the Conman documentation for current version options and additional configuration options available.

One of the additional advantages of configuring Conman to use the libipmiconsole library natively is that Conman is able to detect and manage additional IPMI error cases.

0.19 How do you setup Ganglia or Nagios to monitor IPMI sensors via FreeIPMI?,

Scripts to monitor IPMI via FreeIPMI in Ganglia and Nagios have been developed and are downloadable on the FreeIPMI homepage (<http://www.gnu.org/software/freeipmi/download.html>). Instructions for setup can be found at the top of the scripts.

0.20 Why is the IPMI kernel driver faster than the KCS driver?

Internally the IPMI kernel driver chooses to spin while polling for a response from the base management controller (BMC) while the KCS driver elects to sleep between poll attempts. An operating system's scheduler granularity may be larger than the time it takes to perform a IPMI transaction, thus the wall clock time of the KCS driver is far worse than the IPMI kernel driver. FreeIPMI's KCS driver implements the sleep between poll attempts because it is believed to provide better overall system use. To force the KCS driver to have similar wall clock response time to the IPMI kernel driver, users can specify the 'spinpoll' workaround.

0.21 Why are there so many IPMI compliance bugs?

The IPMI specification is very large. At last check, the IPMI specification was 601 pages. This does not count the various side specifications related to IPMI, including DCMI, PET,

FRU, and the various OEM extension specifications (e.g. Intel Node Manager). Many sections of text can be ambiguous. Many components of IPMI are optional and aren't required to be implemented. There is some leeway for implementation interpretation as well. Ultimately, bugs will happen. In all fairness, FreeIPMI has had bugs too.

A number of the IPMI compliance bugs found by FreeIPMI are documented in the `freeipmi-bugs-issues-and-workarounds.txt` document (you can find it on the website here: <http://www.gnu.org/software/freeipmi/freeipmi-bugs-issues-and-workarounds.txt>).

0.22 How do I get around an IPMI compliance bug on my motherboard?

Most of the FreeIPMI tools and libraries have flags to workaround a large number of IPMI compliance bugs found on motherboards. Please see the appropriate tool manpages or library header files for details on the workarounds available and for what motherboards.

If you believe there is a compliance issue on your motherboard that has not yet been implemented, please contact the maintainers on the freeipmi-devel@gnu.org mailing list.

0.23 How do I program with the FreeIPMI libraries?

If you are looking for a high level library to do Serial-over-LAN (SOL) or IPMI sensor/SEL monitoring, you may wish to look at the `libipmiconsole` and `libipmimonitoring` libraries. These libraries attempt to abstract a large amount of the underlying IPMI detail from developers. The majority of the documentation can be found in the header files. Some examples can be found in the documentation and the FreeIPMI tools that use them.

The `libfreeipmi` library is the core library used by other FreeIPMI libraries and tools. However, it is quite detailed in regards to the IPMI specification and many components of the library will be quite confusing to those unfamiliar with the finer details of the IPMI specification. It is recommended most use the higher level libraries described above.

A more detailed description of the available FreeIPMI libraries can be found in the `freeipmi-libraries.txt` document (you can find it on the website here: <http://www.gnu.org/software/freeipmi/freeipmi-libraries.txt>).

0.24 Where can I get additional help or support?

For help, please email the freeipmi-users@gnu.org mailing list.